

AEM 617

A320 FBW
Case study

The Airbus A320 is a fully fly-by-wire (FBW) aircraft (with 2 exceptions).

This aircraft is the 1st commercial transport FBW FCS, without a complete mechanical backup.

Objectives:

- Enhanced "protection" at the flight envelope boundary
- Load alleviation
- Efficient and ergonomic flight controls

* The computer won't let the pilot break the airplane

What are the disadvantages?
Air France 447


tiny.cc/AEM617A320

airplane fly over

visual approach

"of protection mode"
elevators limited.

Safety:

- Redundancy 5 separate flight computers
- Mechanical Backup: Rudder + Horizontal trim (tested to show control over all envelope)


roll → pitch → heading → altitude, attitude

Hydraulic actuation of all surfaces

Electrical control

- Elevators
- Ailerons
- Roll spoilers
- Tailplane trim
- Slats and flaps
- Speed brakes/lift dumpers
- Trims

Mechanical control

- Rudder
- Tailplane trim
(Reversionary mode)





Figure 4-43. A320 Flight Control Surfaces. (Courtesy of Airbus Industrie)

Source:

Aircraft Flight Control System Design

Raymond and Chenoweth
SAE, 1993

System Controllability and Robustness Architecture



What is the minimum necessary equipment/controls
needed to achieve a survivable landing?

- Altitude *
- Location *
- Heading *
- Airspeed *

In general, the equation of motion are coupled.

In practice, a pilot can fly with elevator, rudder, and thrust.

Airbus split the A320 architecture into 2 primary (yet redundant) systems.

• ELAC: 2 computers controlling elevators and ailerons.

• SEC: 3 computer controllers spoilers and elevators.
plus electromechanical actuator horizontal trim

Intel 80286 and Motorola 68010

The computers are supplied by two different companies. Each ELAC and SEC has a control unit and monitor unit (these units are physically separated). Software is different across systems and control/monitoring units.

Monitoring systems allow crosstalk between all 5 computers.

Also 2 FAC for rudder control

"Flight Augmentation Computers"

The A320 also has 3 separate hydraulic systems.




Figure 4-44. A320 EFCS Architecture. (Courtesy of Airbus Industrie)

A320 control routing redundancy (Segregation)

S = Signal

M = Monitoring

= ELAC and SEC system




Figure 4-45. A320 EFCS Wiring in Wings and in Engine-Burst Exposed Areas. (Courtesy of Airbus Industrie)




Figure 4-46. A320 Pitch Control System. (Courtesy of Airbus Industrie)

- Actuators center upon loss of signal
- Actuators operate in "damping" mode when in standby mode or if hydraulic pressure lost.
Normal operation is one actuator "active" and other in "standby". No fighting.
- Mechanical trim has priority at THS actuator





Figure 4-47. A320 Roll Control System. (Courtesy of Airbus Industrie)

LAF : Load Alleviation

Modify the spanwise lift distribution to minimize wing bending stresses
during maneuvers and turbulence



Controls the outboard spoilers and ailerons on the A320.






Figure 4-48. A320 Yaw Control System. (Courtesy of Airbus Industrie)




Figure 4-50. A320 Slat and Flap Control System. (Courtesy of Airbus Industrie)





Copyright Christian Gagné

AIRLINERS.NET

