

# Aircraft Icing

## NASA Glenn Research Center

Gene Addy, MS, Aerospace Engineer, Icing Branch

# Aircraft Icing Incidents and Accidents

- New York City
- Chicago
- The Phillipines
- Brazil

# Overview

- What is aircraft icing?
- How can it affect an aircraft?
- How can an aircraft be protected from icing?
- How might an icing test be set up?



# Objectives

- Describe difference between ground and inflight icing
- List three types of ice
- List two effects of ice accretion on aircraft
- List three types of ice protection systems
- Setup an icing test of an ice protection system

# What is aircraft icing?

- Ground icing
- **In-flight icing**



NASA  
C-1992-2275




# Basics of inflight icing:

(icing video here)



- Liquid droplets
  - small ~ 10-40 micrometers
  - supercooled to as low as -40 deg
  - aircraft creates nucleation site
  - rate of freezing and accretion depends upon air temperature, airspeed, amount of water per unit area in cloud
- Ice crystals
  - small ~ 100 to 200 micrometers
  - Bounce off surfaces unless partially or fully melted by local above-freezing environment
  - accretion depends upon air temperature, airspeed, amount of water per unit area in cloud

# Aircraft icing envelopes




1. Pressure altitude range: SL to 22,000 ft
2. Maximum vertical extent: 6,500 ft.
3. Horizontal extent: standard 17.4 knots

# Aircraft Inflight Ice Accretions



- Glaze Ice



- Rime Ice




- Scalloped Ice

- Freeze on impact
- Flow before freeze




# Ice Accretions

NACA 23012 - 18 inch chord



$V = 175$  kts  
 $AOA = 5^\circ$   
 $T_t = 28.0$  °F  
 $T_s = 20.8$  °F

NACA 23012 - 72 inch chord




$LWC = 0.64$  g/m<sup>3</sup>  
 $MVD = 15$  um  
Spray = 10 min


Same icing conditions - different size airfoils

# Same icing conditions - different size airfoils


**NACA 23012 - normalized by chord length**




# Icing effects - Length of Exposure




$V = 200$  kts  
 $LWC = 0.75$  g/m<sup>3</sup>  
 $T_t = -2.2$  deg C  
 $MVD = 15$   $\mu$ m  
 $AOA = 2.0$  deg





# Icing effects - Length of Exposure





$V = 200$  kts  
 $LWC = 0.75$  g/m<sup>3</sup>  
 $T_t = -2.2$  deg C  
 $MVD = 15$   $\mu$ m  
 $AOA = 2.0$  deg



# Icing effects – Type of Ice




# Icing effects – Type of Ice




# How to protect aircraft from icing: Ice Protection Systems

- Thermal  
(evaporative and running wet)
  - Heated-air
  - Electrothermal
- Mechanical
- Freezing Point Depressant (FPD)



# Test an Ice Protection System


- A new aircraft has been designed that incorporates a new bleed-air thermal ice protection system.
- Task: plan a test of the new ice protection system
- Steps involved include:






Select  
probable  
icing  
scenarios

- For this airplane, the phases of flight critical for icing are:
  - Hold
    - Warm – air temperature near freezing pt.
    - Cold – air temperature well below freezing pt.
  - Descent
    - Lower power available for icing protection





<b>Flight phase</b>	<b>Alt., ft</b>	<b>V, kts</b>	<b>AOA</b>	<b>Ts, F</b>	<b>Tt, F</b>	<b>LWC</b>	<b>MVD</b>
Warm Hold	15000	180	2	20	27.7	0.5	20
Cold Hold	15000	180	2	-22	-14.3	0.15	20
Descent	10000	180	-1	-4	3.7	0.15	20





• Icing winds tunnels available both in the U.S. and abroad. Considerations:

- Size of tunnel
- Airspeed
- Temperature
- Cloud (LWC, MVD)
- Altitude capability
- Cost







- Must fit in tunnel
- Must retain aspects of wing pertinent to icing – i.e. the leading edge must be closely representative of the aircraft's
- Ice protection system must be representative



Bleed Air System





## Scaling

- Geometric
  - very little – greatly affects collection efficiency
- Cloud conditions
  - very little MVD, some LWC
- Altitude
  - Thermal IPS heat transfer
  - Water evaporation (mass transfer)
  - How to account for this?
    - Similarity parameters
      - Heat transfer: Prandtl No. & Nusselt No.
      - Mass transfer: Schmidt No. & Sherwood No.

# Reynolds analogy

- Momentum transfer, heat transfer, and mass transfer rates are similar
- If transfer rate for one can be established, the other two can be inferred
- Similarity holds only under certain conditions
- In aeronautics, momentum transfer (Reynolds number) is well established

Heat transfer: Nusselt number =  $f(\text{Re})$

Mass transfer, Sherwood number =  $f(\text{Nu})$

# Method

Match (flight and tunnel):

1. Reynolds number, 
$$\text{Re} = \frac{\rho V d}{\mu}$$


2. Cloud parameters:

a) Water loading, 
$$M_w = LWC \times V \times \beta$$

b) Inertia parameter, 
$$K = \frac{\rho_w \delta^2 V}{18 d \mu_a}$$


3. Recovery temperature,

$$T_r = T_s \left( 1.0 + r \left( \frac{\gamma - 1}{2} \right) M^2 \right)$$



	Warm Hold	Alt., ft*	Palt, psia	V, kts	Ts, F	Tt, F	LWC	MVD	Re-2xr	mw	k0	Tr, F	Prantl	Nusselt	Schmidt	Sherwood
<b>Warm Hold</b>																
Ref		15000	8.287	180.0	20.0	27.7	0.50	20.0	128591	29.96	1.504	26.5	0.7113	356.7	0.6259	338.9
Scale		766	14.29	105.6	24.3	26.9	0.85	27.8	128591	29.96	1.504	26.5	0.7113	356.7	0.6271	339.2
<b>Cold Hold</b>																
Ref		15000	8.30	180	-22.0	-14.3	0.15	20.0	139772	9.024	1.523	15.5	0.7121	372.08	0.6267	353.5
Scale		823	14.26	106	-17.8	-15.1	0.25	27.8	139772	9.024	1.523	15.5	0.7120	372.06	0.6290	354.0
<b>Descent</b>																
Ref		10000	10.1	180	-4.0	3.7	0.15	20.0	164186	8.808	1.414	2.5	0.7118	403.19	0.6266	383.1
Scale		1074	14.13	129.8	-0.9	3.1	0.21	24.5	164186	8.808	1.414	2.5	0.7117	403.17	0.6277	383.4





- **Set test matrix to:**


- Investigate various bleed-air flowrates, pressures, and temperatures to determine adequacy and optimum operation
- Help determine adequacy of jet location and distribution as well as extent of IPS coverage

# Caveats

- Reynolds analogy assumptions valid?
  - Boundary layer approximations are valid
  - $Pr$  and  $Sc \approx 1$
  - $dp/dx \approx 0$
- Flight tests usually required to verify IPS operation




# Why is NASA involved in aircraft icing?

- National Advisory Committee for Aeronautics (NACA)
- Continues to conduct aeronautical research
  - Aircraft Safety
  - Fundamental Aeronautics
  - Aeronautics Tests
  - Integrated Systems
  - Airspace Systems




# What does NASA do?

- Studies ice accretion process
- Investigates effects of ice on aircraft
- Develops engineering tools for use in designing and certifying aircraft for flight in icing conditions
- Promotes the development of ice protection systems
- All of the information presented here is from NASA-sponsored research




# NASA Ice accretion simulation codes:

- LEWICE
- GLENNICE




# NASA Ice accretion codes, 3D:

LEWICE3D



# NASA Ice accretion codes, 3D:


LEWICE3D



# NASA aerodynamic performance tests and fundamental flowfield investigations



Dry, aerodynamic wind tunnel studies are conducted using artificial ice shapes. The use of these methods allows for more thorough (real ice melts and sublimates) and cost-effective investigations.





# Conclusions

- Describe difference between ground and inflight icing
- List three types of ice
- List two effects of ice accretion on aircraft
- List three types of ice protection systems
- Setup an icing test of an ice protection system

